


INSTALLATION INSTRUCTIONS (2-1/16") ELECTRICAL GAUGES

PYROMETER

Mounting

These gauges can be mounted in-dash or in Auto Gauge panels (2-5/8" dia. hole for 2-5/8" gauges). Fasten with brackets supplied as shown. (Hookup wire is required.) To assure proper functioning of this instrument, please read instructions thoroughly before installing.




BOTTOM VIEW

1 BEFORE YOU START

1. Read instructions completely before installation.
2. Install pyrometer only when engine is cool and ignition is off.
3. Make sure all necessary tools, materials, and parts are on hand.
4. Disconnect negative (-) battery cable before installing pyrometer.
5. Make sure mounting location does not impair visibility of interfere with driving. Also check behind the mounting location for any wiring or components before drilling.
6. When connecting electrical wire, install crimp terminals and make wire splices as needed. ALWAYS insulate wire splices with electrical tape to prevent shorting.
7. Follow all necessary safety procedures for protection.

NOTE: It may be necessary to reprogram your radio, clock, etc. after reconnecting the battery.



2 INSTALLATION

Yellow - +12V Connection
Black - Good Engine Ground
Choose either White or Amber back light
Red - White Light (+12V Dash)
Orange - Amber Light (+12V Dash)
Pink - Connects To Blue Wire On EGT Probe
Blue - Connects To Pink Wire On EGT Probe

