

Oil Temperature Gauge

OPENING CEREMONY

1

2

3

4

5

6

7

REQUIRE FUNCTION		INSTALLATION
DAY TIME	NIGHT TIME	
WHITE SCALE	WHITE SCALE	WHITE WIRE→connect to ACC. AMBER WIRE→NO connect
AMBER SCALE	AMBER SCALE	WHITE WIRE→NO connect AMBER WIRE→connect to ACC.
WHITE SCALE	AMBER SCALE	WHITE WIRE→ connect to ACC AMBER WIRE→connect to PARKING LAMP
AMBER SCALE	WHITE SCALE	WHITE WIRE→connect to PARKING LAMP AMBER WIRE→connecto to ACC.

8

1.MUTE SELECTER  
SET KEY HOLD AFTER POWER ON.

2.PEAK SELECTER

3.WARNING SET SECECTER