

Water Temperature Gauge

OPENING CEREMONY

1

2

3

4

5

6

7

NOTE:GAUGE REQUIRE FUNCTION

| REQUIRE FUNCTION | | INSTALLATION |
|------------------|-------------|---|
| DAY TIME | NIGHT TIME | |
| WHITE SCALE | WHITE SCALE | WHITE WIRE→connect to ACC. AMBER WIRE→NO connect |
| AMBER SCALE | AMBER SCALE | WHITE WIRE→NO connect AMBER WIRE→connect to ACC. |
| WHITE SCALE | AMBER SCALE | WHITE WIRE→ connect to ACC AMBER WIRE→connect to PARKING LAMP |
| AMBER SCALE | WHITE SCALE | WHITE WIRE→connect to PARKING LAMP AMBER WIRE→connecto to ACC. |

8

1.MUTE SELECTER
SET KEY HOLD AFTER POWER ON.

2.PEAK SELECTER

NORMAL MODE → SET KEY → PEAK MODE → SET KEY → NORMAL MODE

HOLD SET KEY 3SEC → CLEAR PEAK → NORMAL MODE

"PEAK LED FLASH"

3.WARNING SET SECECTER

HOLD SET KEY 5 SEC → SET KEY → WARNING SET MODE → SET KEY → POINTER MOVE SLOWLY

"POINTER LED FLASH"

HOLD SET KEY → OVER 5SEC → POINTER MOVE QUICKLY → NORMAL MODE