


Fuel Press Gauge

OPENING CEREMONY

1




POWER WIRE

SENSOR WIRE.

RED - BATTERY (+).
BLACK - ENGINE GROUND.
WHITE - IGNITION SWITCH 12V+
ORANGE - CONNECT TO 12V DASH LIGHTING.


BACK VIEW

2




45MM

3




4



+

-


5



+

-

6



Fuel pressure regulator

Wind Teflon tape.

Hose union (commercially available)

Three-way joint (commercially available)

Fix tightly with clamps. (commercially available)

Fuel return pipe (low pressure)

Fuel feed pipe (high pressure)

To sensor wire

Sensor

Be sure not to twist.

*Cut the fuel feed pipe and install hose unions.

ORANGE CONNECTOR


SENSOR WIRE

BLACK WHITE

FUEL PRESS SENSOR

7

FUEL PRESS SENSOR




PRESSURE SENDER

G - CONNECT TO SENSOR WIRE WHITE WIRE.

M - CONNECT TO SENSOR WIRE BLACK WIRE.

8



+

-