

ELECTRICAL GAUGES W/PEAK


SMOKE LENS SERIES GREEN & SUPER WHITE LED

(270° SCALE)

Tachometer

OPENING CEREMONY

1



POWER WIRE  
(EITHER SIDE IS OK)


SENSOR WIRE.

WARNING CONNECTOR

RED - BATTERY(+)  
BLACK - BATTERY(-)  
WHITE - NOTE  
ORANGE - NOTE

BACK VIEW

2



DOUBLE-SIDED TYPE VISOR

METER 0.1-0.2in CORD BUFFER METER CUP & HOLDER

SET KEY

1. CYL SECETER


HOLD SET KEY 10 SEC SET KEY

NORMAL MODE → CYL SET MODE → 4-5-6-7-8-9-10-1-2-3 CYL

"POINTER LED FLASH QUICKLY" → OVER 5SEC → NORMAL MODE

3

DOUBLE-SIDED TYPE



CORD

WARNING LIGHT HAVE TO BUY EXTRALY.

4

2. MUTE SELECTER  
SET KEY HOLD AFTER POWER ON.

3. PEAK SELECTER

NORMAL MODE → SET KEY → PEAK MODE → SET KEY → NORMAL MODE

HOLD SET KEY 3SEC → CLEAR PEAK → NORMAL MODE

"PEAK LED FLASH"

4. WARNING SET SECECTER


HOLD SET KEY 5 SEC SET KEY

NORMAL MODE → WARNING SET MODE → SET KEY → POINTER MOVE SLOWLY

"POINTER LED FLASH"

HOLD SET KEY → OVER 5SEC → POINTER MOVE QUICKLY → NORMAL MODE


5



+

-

6



SENSOR WIRE

WHITE

RED CONNECTOR

TACHOMETER SIGNAL WIRE

ECU (ENGING COMPUTER UNIT)


BACK VIEW

7

NOTE:GAUGE REQUIRE FUNCTION

REQUIRE FUNCTION		INSTALLATION
DAY TIME	NIGHT TIME	
WHITE SCALE	WHITE SCALE	WHITE WIRE→connect to ACC. AMBER WIRE→NO connect
GREEN SCALE	GREEN SCALE	WHITE WIRE→NO connect AMBER WIRE→connect to ACC.
WHITE SCALE	GREEN SCALE	WHITE WIRE→ connect to ACC AMBER WIRE→connect to PARKING LAMP.
GREEN SCALE	WHITE SCALE	WHITE WIRE→connect to PARKING LAMP AMBER WIRE→connecto to ACC.

8



+

-