

INSTALLATION INSTRUCTIONS

ELECTRICAL GAUGES

SMOKE LENS SERIES WHITE & AMBER LED DISPLAY

OPENING CEREMONY

Exhaust Gas Temp Gauge

1

BACK VIEW

2

3 **EXHAUST GAS TEMP SENSOR**

Drill a hole On either position And installing the 1/8PT thread jointer

PINK - CONNECT TO SENSOR WIRE HARNESS(WHITE WIRE).
BLUE - CONNECT TO SENSOR WIRE HARNESS(BLACK WIRE).

4

BACK VIEW

Press gauge

5

*Sensor Attachment Have To Buy Extraly

6

To sensor wire
Be sure not to twist

7

PRESS SENSOR

8

BACK VIEW

Temp Gauge

9

*Sensor Attachment Have To Buy Extraly

*Cut the upper hose and connect the sensor attachment between hoses.

10

*Sensor Attachment Have To Buy Extraly

11 **TEMP SENSOR**

WHITE - CONNECT TO SENSOR WIRE HARNESS (WHITE WIRE).
BLACK - CONNECT TO SENSOR WIRE HARNESS (BLACK WIRE).

12

BACK VIEW

1. Connect power wire (RED) to +12V battery wire.
2. Connect power wire (BLACK) to ground, negative (-) battery terminal or a good chassis ground.
3. ORANGE - Note
4. WHITE - Note

NOTE: GAUGE REQUIRE FUNCTION

REQUIRE FUNCTION		INSTALLATION
DAYTIME	NIGHT TIME	
WHITE SCALE	WHITE SCALE	WHITE WIRE → CONNECT TO ACC
		ORANGE WIRE → NO CONNECT
AMBER RED SCALE	AMBER RED SCALE	WHITE WIRE → NO CONNECT
		ORANGE WIRE → CONNECT TO ACC
WHITE SCALE	AMBER RED SCALE	WHITE WIRE → CONNECT TO ACC
	SCALE	ORNAGE WIRE → CONNECT TO PARKING LAMP
AMBER RED SCALE	WHITE SCALE	ORANGE WIRE → CONNECT TO ACC
	SCALE	WHITE WIRE → CONNECT TO PARKING LAMP

