INSTALLATION INSTRUCTIONS

ELECTRICAL GAUGES

TRANSPARENT LENS SERIES AMBER RED LED DISPLAY

Air fuel / ratio OPENING CEREMONY 3 4 POWER WIRE SENSOR WIRE. RED - BATTERY (+). BLACK - ENGINE GROUND. WHITE - IGNITION SWITCH 12V+ ORANGE - CONNECT TO 12V DASH LIGHTING. **BACK VIEW** 6 5 SENSOR WIRE WHITE 02 SENSOR SIGNAL WIRE RED CONNECTOR

ECU

(ENGING COMPUTER UNIT)

BACK VIEW